

5100 PUSH TURN

GRIP	=	No.
2,00 - 2,99		02
3,00 - 3,99		03
4,00 - 4,99		04
5,00 - 5,99		05
6,00 - 6,99		06
7,00 - 7,99		07
8,00 - 8,99		08
9,00 - 9,99		09
10,00 - 10,99		10
11,00 - 11,99		11
12,00 - 12,99		12
13,00 - 13,99		13
14,00 - 14,99		14
15,00 - 15,99		15
16,00 - 16,99		16
17,00 - 17,99		17
18,00 - 18,99		18
19,00 - 19,99		19
20,00 - 20,99		20
21,00 - 21,99		21
22,00 - 22,99		22
23,00 - 23,99		23
24,00 - 24,99		24
25,00 - 25,99		25
26,00 - 26,99		26
27,00 - 27,99		27
28,00 - 28,99		28
29,00 - 29,99		29
30,00 - 30,99		30
31,00 - 31,99		31
32,00 - 32,99		32
33,00 - 33,99		33
34,00 - 34,99		34
35,00 - 35,99		35
36,00 - 36,99		36
37,00 - 37,99		37
38,00 - 38,99		38
39,00 - 39,99		39
40,00 - 30,49		40

mm

